# BUNN EQUIPMENT TROUBLESHOOTING AND TRAINING

#### ALL COFFEE EQUIPMENT

# IS THE UNIT PLUGGED IN? IS THE WATER TURNED ON (COFFEE BREWERS)?

#### AIR POT COFFEE BREWER

#### 1. Coffee Is Too Strong/Weak

-check temperature (at sprayhead) \*Should be 195-200 degrees -check if sprayhead is in place -check right amount of coffee grounds -water volume properly set -water amount should be <sup>3</sup>/<sub>4</sub> full -check for cleanliness 2. No Hot Water -heater switch in back of the brewer (some models) in "on" position -thermostat rotated to fully clockwise (demonstration) 3. Will Not Brew Coffee -"on/off" switch in "on" position -if water is hot, operate as pour-over until service arrives 4. Coffee Level is Not Correct -air pot empty before brewing -reset level from front switches (demonstration) **5. Grounds Over-Flowing the Funnel** -check amount of coffee being used -check sprayhead in place

-check for correct paper filter size





# **PORTION COFFEE GRINDER**

Grinder Will Not Start

 check re-set button on right side of the grinder
 double check power source

 Grinds the Wrong Amount of Grounds

 clean hopper
 slide gates working (demonstration)
 adjust timer (demonstration)

 Spraying Coffee In The Funnel

 clean de-chaffer springs

 Coffee Is Too Course or Too Fine

 adjust grind setting (demonstration)
 compare to samples

## **DUAL SATELLITE BREWER**

### 1. Coffee is Too Strong/Weak

-batch select in right position -sprayhead in place -check for correct amount of coffee grounds -check water temperature at sprayhead -check water volume for batch sizes -water amount should be <sup>3</sup>/<sub>4</sub> full, both sides -check for server cleanliness 2. Brewed Coffee Level is Not Correct -sprayhead in place and clean -re-set timer (demonstration) 3. No Hot Water -check water temperature at sprayhead -check ready light in "lighted" position -check for hot water from faucet. -check thermostat in on position 4. Will Not Brew -"on/off" switch in "on" position





FOR BUNN-O-MATIC TECHNICAL SUPPORT, PLEASE CALL 800-286-6070

